





www.airkrafters.com

support@airkrafters.com

AIRKRAFTERS, INC. 21935 Van Buren St. Unit B-6 Grand Terrace, CA 92313 DESIGNED AND MANUFACTURED IN CALIFORNIA

PATENT PENDING

the 'airkrafters' trade name and airkrafters logo are trademarks belonging to airkrafters, inc. © 2020 airkrafters, inc.



CARRYING CAPACITY 100LB MAX

DO NOT USE PLUSNUTS ON A FRAME WITH 1" WIDE CROSSMEMBERS --- TYPICALLY, 30' AND LONGER COACHES HAVE NARROW 1" CROSSMEMBERS ---

FRAME CROSSMEMBERS MUST BE 2" WIDE FOR MOUNTING WITH 3/8" PLUSNUTS

INSTALLATION ON A COACH WITH NARROW 1" CROSSMEMBERS WILL REQUIRE THE USE OF A BACKING PLATE OR SPEEDNUTS. PLEASE CONTACT AIRKRAFTERS OR A DISTRIBUTOR/INSTALLATION SHOP FOR GUIDANCE ON PROPER INSTALLATION PROCEDURE.

APPLY PERMATEX HIGH STRENGTH REMOVABLE ORANGE OR PERMATEX HIGH STRENGTH PERMANENT RED THREADLOCKER TO ALL MOUNTING BOLTS

- THE PREDRILLED MOUNTING HOLES ON THE CARRIER ARE 24" CENTER-TO-CENTER -

- SOME COACHES WILL HAVE CROSSMEMBERS THAT MAY DIFFER FROM THIS -

THEREFORE, IT MAY BE NECESSARY TO DRILL ADDITIONAL MOUNTING HOLES IN THE CARRIER THAT MATCH THE CENTER-TO-CENTER MEASUREMENT/SPAN BETWEEN ABNORMALLY/IRREGULARLY SPACED CROSSMEMBERS



www.airkrafters.com

support@airkrafters.com AIRKRAFTERS, INC. 3257 ROYAL OAKS DR. UNIT 101 THOUSAND OAKS, CA 91362